



Building a line of defense Use baffle boards of 3/4" plywood sheets with a soft felt or foam rubber to close off vents, low windows, and doors incase of floodwater. Using plastic tarp between structure and sandbags helps to keep flood water from seeping between the house siding and foundation sills Care should be taken to place sandbags against one another. Complete each layer before starting the next layer. Limit placement of two layers unless a building is used as a backing or sandbags are stacked in a pyramid, or half pyramid fashion Note: stagger the second and subsequent layers of bags like a brick pattern on a wall